

Slide 1



Add a New Home Button.



<u>ESSENTIALS</u>	<u>ADVANCED</u>
MX-2651	MX-3071
MX-3051	MX-3571
MX-3551	MX-4071
MX-4051	

Slide 2

The screenshot shows a printer control panel interface. At the top, there is a status bar with icons for Easy Copy, Easy Scan, HDD File retrieve, Sharp OSA, and a printer icon. The printer icon is labeled 'PRINTER' and has a dropdown arrow. To the right of the printer icon is a 'Job Status' button. Below the status bar, the time '03:00 PM' is displayed, with a red arrow pointing to it from the right. The main area contains four large touchable buttons: 'Easy Copy' (green icon), 'Easy Scan' (orange icon), 'Print Release' (blue circular arrow icon), and 'Sharp OSA' (Sharp OSA logo icon). Below these buttons is a row of six small circular indicators, with the first one being blue. At the bottom, there is a navigation bar with icons for 'Operation Guide', 'Enlarge Display Mode', 'Settings', 'Total Count', 'LCD Control', and 'Job Status'. On the left side of the bottom bar, there is a 'Toner Quantity' section with four horizontal bars representing Bk (black), C (cyan), M (magenta), and Y (yellow). A white callout box with a black border is overlaid on the bottom bar, containing the text 'Select the Side Bar tab.' with 'Side Bar' in red.

Easy Copy Easy Scan HDD File retrieve Sharp OSA PRINTER Job Status

03:00 PM


Easy Copy Easy Scan Print Release Sharp OSA

Select the Side Bar tab.

Toner Quantity Bk C M Y

Operation Guide Enlarge Display Mode Settings Total Count LCD Control Job Status

Slide 3



Slide 4

Easy Copy Easy Scan HDD File retrieve Sharp OSA LINE PRINTER Job Status

Administrator Password


Please input Admin Password.
(5 or more and up to 255 characters)

Password

Select the **Password** text box.

CA OK

Slide 5



Slide 6

The screenshot shows a control panel interface for a Sharp OSA device. At the top, there is a dark grey header bar with several icons and labels: 'Easy Copy' (green icon), 'Easy Scan' (orange icon), 'HDD File retrieve' (yellow folder icon), 'Sharp OSA' (logo), 'LINE' (checkbox), 'PRINTER' (checkbox with wireless icon), and 'Job Status' (text). Below the header, the main area has a light grey background. The title 'Administrator Password' is displayed in large black font. Below it, the instruction 'Please input Admin Password. (5 or more and up to 255 characters)' is shown. A text input field labeled 'Password' contains a series of asterisks. A red arrow points to a blue 'OK' button at the bottom right. In the bottom left corner, there is a black button with 'CA' in yellow. A central box contains the text 'Select OK.' in black and red. A help icon (?) and a close icon (X) are in the top right corner of the main area.

Slide 7

Easy Copy Easy Scan HDD File retrieve Logout Administrator LINE PRINTER Job Status

03:04 PM

Easy Copy Easy Scan HDD File retrieve Sharp OSA

Select the key to add or change.

You can now edit the **Home Page Layout.**

Slide 8

The screenshot shows a control panel interface. At the top, there is a navigation bar with several icons and labels: 'Easy Copy' (green icon), 'Easy Scan' (orange icon), 'HDD File retrieve' (folder icon), 'Logout Administrator' (logout icon), 'LINE' (checkbox), 'PRINTER' (checkbox), and 'Job Status' (printer icon). Below the navigation bar, the time '03:05 PM' is displayed. The main area contains four large, dark grey buttons with icons and text: 'Easy Copy' (green icon), 'Easy Scan' (orange icon), 'Print Release' (circular printer icon), and 'Sharp OSA' (Sharp logo and 'Sharp Open Systems Architecture' text). Below these buttons is a horizontal row of 12 dots, with the first dot highlighted in blue. To the right of the dots is a circular button with a right-pointing arrow, which is highlighted by a red arrow. At the bottom of the screen, a white text box contains the instruction 'Select the right arrow.' A trash can icon is visible in the bottom left corner.

Slide 9

The screenshot shows a software interface with a dark grey top bar. On the left, there are icons for 'Easy Copy', 'Easy Scan', and 'HDD File retrieve'. On the right, there are 'Logout Administrator', 'LINE', 'PRINTER', and 'Job Status' buttons. Below the top bar, the time '03:06 PM' is displayed. The main area contains four large dark grey buttons: 'Dropbox Connector' (with a blue logo), 'Copy' (with a document icon), 'E-Mail' (with an envelope icon), and an empty icon with a white plus sign inside a dashed red square. At the bottom, a white box contains the text 'Select the Empty Icon.' and a trash can icon is visible in the bottom left corner.

Slide 10

The screenshot shows a user interface for a device. At the top, there is a navigation bar with icons for 'Easy Copy', 'Easy Scan', 'HDD File retrieve', 'Logout Administrator', 'LINE', and 'PRINTER'. A 'Job Status' button is on the right. The time '03:06 PM' is displayed in the top right corner. A dialog box titled 'Select Functions to add to Home.' is open in the center, containing a list of functions: Copy, E-Mail, FTP/Desktop, Data Entry, Metadata Setting, Address Book, Global, Program List (Copy), Internet Fax, Network Folder, PC Scan, Program List (Image Send), and Address Control. The 'Internet Fax' option is highlighted with a red border. An 'OK' button is in the top right of the dialog. A text box at the bottom of the dialog reads 'Select the Button you would like to add.' with the word 'Button' in red.

Select Functions to add to Home.	
Copy	Program List (Copy)
E-Mail	Internet Fax
FTP/Desktop	Network Folder
Data Entry	PC Scan
Metadata Setting	Program List (Image Send)
Address Book	Address Control
Global	

Select the **Button** you would like to add.

Slide 11

The screenshot shows a software interface with a dark grey top navigation bar. From left to right, it contains: 'Easy Copy' with a green document icon, 'Easy Scan' with an orange scanner icon, 'HDD File retrieve' with a folder icon, a 'Logout Administrator' button with a right-pointing arrow, a 'LINE' status indicator with a grey square, a 'PRINTER' status indicator with a blue square and a printer icon, and a 'Job Status' button. Below the navigation bar, the main content area has a light grey background. In the top right corner of this area, the time '03:08 PM' is displayed next to a left-pointing arrow. The main content area features four dark grey buttons with rounded corners: 'Dropbox Connector' with a blue logo, 'Copy' with a green document icon, 'E-Mail' with a white envelope icon, and 'Internet Fax' with a blue telephone handset and a globe icon. The 'Internet Fax' button is highlighted with a red border. Below the buttons is a horizontal row of ten small grey circles, with the second circle from the left being blue. Navigation arrows are present on the far left and far right of this row. At the bottom of the interface is a dark grey bar containing a trash can icon on the left and a white text box in the center that reads 'The Button is now displayed.' with the word 'Button' in red.

Slide 12

mv™
SHARP

Congratulations, you have successfully
Added a New Home Button.

<u>ESSENTIALS</u>	<u>ADVANCED</u>
MX-2651	MX-3071
MX-3051	MX-3571
MX-3551	MX-4071
MX-4051	