

Slide 1




The advertisement features a dark teal background with a semi-transparent image of a business meeting. In the top left corner is the Sharp logo, consisting of a stylized 'm' and 'v' in a square followed by 'TM', and the word 'SHARP' in red below it. To the right of the logo, the text 'Easy Scan.' is displayed in a large, white, sans-serif font. On the right side of the image is a large, white Sharp MX Series multifunction copier with a color touchscreen control panel. At the bottom, there are two columns of model numbers under the headings 'ESSENTIALS' and 'ADVANCED'.

ESSENTIALS	ADVANCED
MX-2651	MX-3071
MX-3051	MX-3571
MX-3551	MX-4071
MX-4051	


Slide 2



Slide 3



Slide 4



Slide 5

The screenshot displays the Sharp OSA (Office System Architecture) interface. At the top, there is a navigation bar with icons for 'Easy Copy', 'Easy Scan', 'HDD File retrieve', and 'Sharp OSA'. To the right of these icons are checkboxes for 'LINE' and 'PRINTER', and a 'Job Status' button. Below the navigation bar, there is a search bar with the text 'Sample3' and 'sample3@internet.com'. To the right of the search bar are buttons for '2', '+', a magnifying glass icon, and 'OK'. Below the search bar, there is a 'Sort' button with a dropdown arrow and a '1/2' indicator. A list of samples is shown below the search bar, with 'Sample1' and 'Sample3' highlighted in blue. Red arrows point to 'Sample1' and 'Sample3'. To the right of the list is a vertical alphabetical index (A, D, G, J, M, P, T, W). At the bottom left, there is a 'Frequent Use' button and a 'Category' dropdown menu set to 'All'. A large white box with the text 'Select Destinations.' is overlaid on the bottom right. To the right of the 'Select Destinations.' box are two buttons: 'B/W Start' and 'Color Start'.

Address: Sample3
sample3@internet.com

2 + 🔍 OK

1/2 ↓ Sort

✓ ✉ Sample1

✉ Sample2

✓ ✉ Sample3

A
D
G
J
M
P
T
W


CA

Select Destinations.


Frequent Use Category All

B/W Start Color Start

Slide 6



Slide 7



Slide 8



The slide features a dark teal background with a semi-transparent image of a business meeting. In the top left corner is the Sharp logo, consisting of a stylized 'm' and 'v' in a square followed by 'TM', with the word 'SHARP' in red below it. In the top right, the text 'Congratulations, you have used Easy Scan.' is displayed in white. On the right side, a large, white Sharp MX Series multifunction copier is shown, featuring a large color touchscreen control panel. At the bottom, there are two columns of model numbers under the headings 'ESSENTIALS' and 'ADVANCED'.

ESSENTIALS

- MX-2651
- MX-3051
- MX-3551
- MX-4051

ADVANCED

- MX-3071
- MX-3571
- MX-4071