

Slide 1


Changing the Button Layout.



The image shows two Sharp MX-B376W and MX-B476W multifunction copiers in a modern office setting. The copiers are white with grey accents and feature a control panel with a color display and buttons. The background shows a blurred office scene with people working at desks. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W

Slide 2




The screenshot shows a web browser window with the address bar set to **10.10.10.10**. The browser's address bar and tabs are visible at the top. The Sharp logo is in the top left corner. Below the logo is a navigation bar with tabs: **Status**, **Address Book**, **Document Operations**, **User Control**, and **System Settings**. The **Status** tab is selected, and the **Machine Identification** sub-tab is active. On the left side of the **Machine Identification** page, there is a sidebar menu with options: **Machine Identification**, **Total Count**, **Device Status**, **Network Status**, **Firmware Version**, **Power Reset**, **Data List**, **List for User**, and **List for Administrator**. The main content area of the **Machine Identification** page has a title **Machine Identification** and an **Update(R)** button. Below this, there is a diagram of the Sharp MX-M6070 machine. To the right of the diagram, the following information is displayed:

Unit Serial Number:	7501826000
Name:	Not Set
Model Name:	MX-M6070
Machine Location:	Not Set
Current Status:	Cover Open
Memo:	Not Set

Below the screenshot, a text box contains the following instructions:

With your web browser open, enter the **TCP/IP Address** of the machine in the address bar. Press **Enter** on the computer **Keyboard**.

Slide 3



The image shows the SHARP My Viewlet interface. At the top left is the SHARP logo. In the top right corner, there is a language dropdown menu set to "American English". Below the logo is a horizontal navigation bar with five tabs: "Status", "Address Book", "Document Operations", "User Control", and "System Settings". The "System Settings" tab is highlighted with a blue border and a red arrow pointing to it. Below the navigation bar is a large grey sidebar on the left. The main content area displays a grid of settings tiles. The tiles are arranged in four rows. The first row contains "Home Screen Settings", "Copy Settings", and "Printer Settings". The second row contains "Image Send Settings", "Document Filing Settings", and "Sharp OSA Settings". The third row contains "Common Settings", "Network Settings", and "Security Settings". The fourth row contains "Energy Save", "System Control", "Image Quality Adjustment", and "Init. Install. Settings". At the bottom of the screen, there is a white box with a black border containing the text "Select System Settings.".

SHARP

Operat
American English

Status Address Book Document Operations User Control **System Settings**

Home Screen Settings Copy Settings Printer Settings

Image Send Settings Document Filing Settings Sharp OSA Settings

Common Settings Network Settings Security Settings

Energy Save

System Control Image Quality Adjustment Init. Install. Settings

Select **System Settings**.

Slide 4



Ar

Status	Address Book	Document Operations	User Control	System Settings
	 Home Screen Settings	 Copy Settings		
	 Image Send Settings	 Document Filing Settings		
	 Common Settings	 Network Settings		
	 Energy Save			
	 System Control	 Image Quality Adjustment		
	Select Home Screen Settings.			

Slide 5



Login

Login(P) Cancel(C)

Authority: admin

Login Name: Administrator

Password: (5-255digit)

Please enter the User Authentication information. This message can be edited from System Setting.

Login(P) Cancel(C)

Enter the Administrator Password.
Select Login.

Slide 6

Condition Settings

Update(R)

Template:

Key Layout of the Screen:



Change Text Color On Home Screen:

1. Scrolling Area:

☒ White

☐ Black

2. Fixed Area:

☒ White

3. Clock:

☐ White

Under **Template**, select a pattern.

Slide 7

Update(R)

Template: Pattern 2

Key Layout of the Screen:

Change Text Color On Home Screen:
1. Scrolling Area:
☒ White
☐ Black
2. Fixed Area:
☒ White
☐ Black
3. Clock:
☐ White
☒ Black

Submit(U)

Select Submit.

Slide 8

User Name: Admin

Address Book Document Operations User Control System Settings

Condition Settings

Update(R)

"Your request was successfully processed."

Template: Pattern 2

Key Layout of the Screen:



Change Text Color On Home Screen:


1. Scrolling Area: ☒ White ☐ Black

2. Fixed Area: ☒ White ☐ Black

3. Clock: ☐ White ☐ Black

A confirmation message is displayed.

Slide 9



Slide 10

Congratulations, you have changed the
Button Layout.



The image shows two white Sharp multifunction copiers, the MX-B376W and MX-B476W, standing in a modern office environment. The copiers are tall and feature multiple paper trays at the bottom. The MX-B476W on the right has a larger, more prominent control panel with a color touchscreen display. The background is a dimly lit office with people working at desks. In the top right corner, there is a logo with the letters 'mv' in a stylized font, followed by 'TM', and the word 'SHARP' in red capital letters below it.

MX-B376W
MX-B476W

mvTM
SHARP