

Slide 1

Easy Fax.



The image shows two Sharp multifunction copiers, the MX-B376W and MX-B476W, in a dimly lit office environment. The copiers are white with grey accents and feature a control panel with a small screen and buttons. The background shows a blurred office scene with people working at a desk. The Sharp logo and 'mv' trademark are visible in the top right corner.


MX-B376W
MX-B476W

Slide 2




Place your originals **Face Up** in
the document feeder.

Slide 3



Slide 4



Slide 5

The image shows a control panel for a fax machine. At the top, there is a status bar with icons for Easy Scan, HDD File retrieve, Sharp OSA, LINE, and PRINTER, along with a Job Status button. Below this is a large display area. At the top of the display area is an 'Address' field containing the number '5551236985'. To the right of the address field are buttons for '1' and '+'. Further right is a blue 'OK' button. Below the address field is a numeric keypad with buttons for digits 1-9, 0, and #, as well as a 'Pause' button and a 'Sub Address' button. At the bottom of the keypad is a pink button labeled 'C'. Below the keypad is a row of buttons: a yellow 'CA' button, a 'P' button with a fax icon, a text box containing the instruction 'Use the Keypad to enter a fax number.', and a large blue 'Start' button with a green play icon.

Address 5551236985 1 + OK

1 2 3 Pause

4 5 6 Sub Address

7 8 9

✕ 0 # C

CA P Use the Keypad to enter a fax number. Start

Slide 6

The image shows the Sharp OSA (Office System Assistant) interface. At the top, there is a status bar with icons for Easy Scan, HDD File retrieve, and Sharp OSA, along with checkboxes for LINE and PRINTER, and a Job Status button. The main area displays an 'Address' field with the number '5551236985' and a '1' button. Below this is a numeric keypad with buttons for 1-9, 0, #, and a 'C' (Clear) button. A red arrow points from the 'C' button down to the 'Start' button at the bottom right. The bottom bar contains a 'CA' button, a 'Preview' button, a 'Select Start.' button, and the 'Start' button.

Address 5551236985 1 + OK

1 2 3 Pause
4 5 6 Sub Address
7 8 9
× 0 # C

CA Preview Select Start. Start

Slide 7

Congratulations, you have
used Easy Fax.



The image shows two white Sharp multifunction copiers, the MX-B376W and MX-B476W, standing in a modern office environment. The copiers are tall, white, and feature multiple paper trays at the bottom. The MX-B476W on the right is slightly larger than the MX-B376W on the left. Both machines have a control panel with a small screen and several buttons. In the background, a man in a suit is standing and talking to two women seated at a conference table. The Sharp logo and 'mv' trademark are visible in the top right corner of the image.

MX-B376W
MX-B476W