

Slide 1


Fax Finishing.



The image shows two Sharp multifunction copiers, the MX-B376W and MX-B476W, in a modern office environment. The copiers are white with grey accents and feature large touchscreens. The background shows a blurred office scene with people working at desks. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W

Slide 2



With your web browser open, enter the **TCP/IP Address** of the machine in the address bar. Press **Enter** on the computer **Keyboard**.

Slide 3

The screenshot displays the SHARP My Viewlet web interface. At the top left is the SHARP logo. In the top right, there are links for "Operation Manual Download" and "Sitemap", a language dropdown set to "American English", a search bar, and a "Login" button with a red arrow pointing to it. Below the top navigation bar is a secondary menu with tabs: "Status", "Address Book", "Document Operations", "User Control", and "System Settings". The "Status" tab is active, showing a left-hand sidebar with options: "Machine Identification" (selected), "Total Count", "Device Status", "Network Status", "Firmware Version", "Power Reset", "Data List", "List for User", and "List for Administrator". The main content area is titled "Machine Identification" and includes an "Update(R)" button. Below this is an illustration of a Sharp multifunction printer. To the right of the illustration, the following information is displayed:

Unit Serial Number:	8F00183300
Name:	Not Set
Model Name:	Not Set
Machine Location:	Not Set
Current Status:	Online
Memo:	Not Set

At the bottom of the page, there is a "Supply Status" section with a large "Select Login" button. A "Top of Page" link is located in the bottom right corner.

Slide 4

SHARPAmerican English ▾

Login

Login(P)Cancel(C)

Authority:admin
Login Name:Administrator ▾
Password:.....(5-255digit)


Please enter the User Authentication information. This message can be edited from System Settings.

Login(P)Cancel(C)

Enter the **Password**. Select **Login**.

^ Top of Page

Slide 5



SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Machine Identification

Update(R)

Unit Serial Number: 8F00183300

Name: Not Set

Model Name: Not Set


Machine Location: Not Set

Current Status: Online

Memo: Not Set

Supply Select **System Settings.** Top of Page

Slide 6



SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Home Screen Settings Copy Settings Printer Settings

Image Send Settings Document Filing Settings Sharp OSA Settings

Common Settings Network Settings Security Settings

Energy Save

System Control Image Quality Adjustment Init. Install. Settings

Select Image Send Settings.

Top of Page

Slide 7

The screenshot shows the SHARP My Viewlet interface. At the top left is the SHARP logo. At the top right are links for 'Operation Manual Download' and 'Sitemap', a language dropdown set to 'American English', a search bar, and a 'Logout' button. Below this is a navigation bar with tabs: 'Status', 'Address Book', 'Document Operations', 'User Control', and 'System Settings' (which is selected). The main content area is titled 'Image Send Settings' and includes a 'Back to Menu List' link. It contains five settings buttons: 'Common Settings', 'Scan Settings', 'Fax Settings', 'Fax Data Receive / Forward (Manual)', and 'Inbound Routing Settings'. A red arrow points to the 'Fax Data Receive / Forward (Manual)' button. At the bottom, a text box contains the instruction 'Select Fax Data Receive / Forward.' and a 'Top of Page' button is on the right.

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Image Send Settings

Back to Menu List

Common Settings Scan Settings Fax Settings

Fax Data Receive / Forward (Manual) Inbound Routing Settings

Select **Fax Data Receive / Forward.**

Top of Page

Slide 8

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control System Settings

Image Send Settings

Fax Data Receive/Forward (Manual)

Submit(U) Update(R)

Back to Menu List

Fax Settings

Receive Setting: Auto Reception

☐ Staple

Submit(U) Update(R)

Select **Staple**. Select **Submit**.

Top of Page

Slide 9

The screenshot shows the SHARP My Viewlet interface. At the top, there is a header with the SHARP logo, a language dropdown set to "American English", a search bar, and links for "Operation Manual Download" and "Sitemap". Below the header is a navigation bar with tabs: "Status", "Address Book", "Document Operations", "User Control", and "System Settings". The "System Settings" tab is active. On the left, a sidebar menu shows "Image Send Settings" and "Fax Data Receive/Forward (Manual)". The main content area is titled "Fax Data Receive/Forward (Manual)" and contains a "Submit(U)" button and an "Update(R)" button. A red box highlights a confirmation message: "Your request was successfully processed." Below this, there is a "Fax Settings" section with a "Receive Setting:" label, a dropdown menu set to "Auto Reception", and a checked checkbox for "Staple". At the bottom of the settings section, there are "Submit(U)" and "Update(R)" buttons. A large text box at the bottom of the slide states: "A confirmation messages is displayed." A "Back to Menu List" link is visible on the right side of the main content area.

Slide 10

The screenshot displays the SHARP My Viewlet web interface. At the top, the SHARP logo is on the left, and links for 'Operation Manual Download' and 'Sitemap' are on the right. A language dropdown is set to 'American English', and the user is logged in as 'Administrator' with a 'Logout' button. A navigation bar contains tabs for 'Status', 'Address Book', 'Document Operations', 'User Control', and 'System Settings'. The 'System Settings' tab is active, and its sub-menu is open, showing 'Image Send Settings' (highlighted with a red arrow) and 'Fax Data Receive/Forward (Manual)'. The 'Fax Data Receive/Forward (Manual)' page is currently displayed, showing a success message: 'Your request was successfully processed.' Below this is the 'Fax Settings' section, which includes a 'Receive Setting:' dropdown set to 'Auto Reception' and a checked 'Staple' checkbox. At the bottom of the settings section are 'Submit(U)' and 'Update(R)' buttons. A large red text box at the bottom of the page reads 'Select Image Send Settings.' with a 'Top of Page' button to its right.

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control System Settings

Image Send Settings ← Fax Data Receive/Forward (Manual)

Submit(U) Update(R) Back to Menu List

"Your request was successfully processed."

Fax Settings

Receive Setting: Auto Reception

☒ Staple

Submit(U) Update(R)

Select Image Send Settings.

Top of Page

Slide 11

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Image Send Settings

Back to Menu List

Common Settings Scan Settings **Fax Settings**

Fax Data Receive /Forward (Manual) Inbound Routing Settings

Select **Fax Settings**.

Top of Page

Slide 12

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control System Settings

Image Send Settings
Fax Settings
Default Settings
Send Settings
Receive Settings
Fax Polling Security
F-Code Memory Box

Default Settings

Submit(U) Update(R) Back to Menu List

Resolution Setting: ☐ Apply the Resolution Set when Stored

Standard

☐ Half Tone

Dial Mode Setting: Tone

☒ Auto Wake Up Print

Pause Time

Select Receive Settings.

Top of Page

Slide 13

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Image Send Settings
Fax Settings
Default Settings
Send Settings
▶ **Receive Settings**
Fax Polling Security
F-Code Memory Box

Receive Settings

Submit(U) Update(R) Back to Menu List

Number of Calls in Auto Reception: 2 Time(s)

☒ 2-Sided Printing of Received Data

☒ Auto Receive Reduce Setting


Print Style Setting: Auto Size Select

Set the Telephone Number for Data Forwarding:
Forwarding Address Number Setting (Up to 64 characters)

Top of Page

To automatically duplex multi-page faxes,
select **2-Sided Printing of Received Data**.

Slide 14



SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control System Settings

Image Send Settings
Fax Settings
Default Settings
Send Settings
Receive Settings
Fax Polling Security
F-Code Memory Box

Receive Settings

Submit(U) Update(R) Back to Menu List

Number of Calls in Auto Reception: 2 Time(s)

☒ 2-Sided Printing of Received Data

☒ Auto Receive Reduce Setting

Print Style Setting: Auto Size Select


Set the Telephone Number for Data Forwarding:
Forwarding Address Number Setting (Up to 64 characters)

☐ Receiving Date & Time Print Inside the Received Image

Top of Page

Select Submit.

Slide 15



The screenshot displays the SHARP My Viewlet web interface. At the top, the SHARP logo is on the left, and links for 'Operation Manual Download' and 'Sitemap' are on the right. Below these, there's a language dropdown set to 'American English' and a search bar. The user is logged in as 'Administrator' with a 'Logout' button. The main navigation bar includes 'Status', 'Address Book', 'Document Operations', 'User Control', and 'System Settings'. The left sidebar lists settings categories: 'Image Send Settings', 'Fax Settings', 'Default Settings', 'Send Settings', 'Receive Settings' (highlighted), 'Fax Polling Security', and 'F-Code Memory Box'. The 'Receive Settings' page is active, showing a 'Submit(U)' button and an 'Update(R)' button. A red-bordered box highlights the message: "Your request was successfully processed." Below this, settings for 'Number of Calls in Auto Reception' (set to 2), '2-Sided Printing of Received Data' (checked), 'Auto Receive Reduce Setting' (checked), 'Print Style Setting' (set to Auto Size Select), and 'Forwarding Address Number Setting' (empty) are visible. A 'Back to Menu List' link is in the top right of the settings area. A 'Top of Page' button is at the bottom right.

"Your request was successfully processed."

Number of Calls in Auto Reception: 2 Time(s)

☒ 2-Sided Printing of Received Data

☒ Auto Receive Reduce Setting

Print Style Setting: Auto Size Select

Set the Telephone Number for Data Forwarding:

Forwarding Address Number Setting (Up to 64 characters)

A confirmation message is displayed.

Back to Menu List

Top of Page

Slide 16

Congratulations, you have configured
Fax Finishing.



The image shows two Sharp multifunction copiers, the MX-B376W and MX-B476W, in a dimly lit office environment. The copiers are white with multiple paper trays and a control panel. In the background, a man in a suit is standing and talking to two seated people at a conference table. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W