


Slide 1

Setting the Power On and Power Off Schedule.



MX-B376W
MX-B476W

Slide 2



With your web browser open, enter the **TCP/IP Address** of the machine in the address bar. Press **Enter** on the computer **Keyboard**.

Slide 3

The screenshot displays the SHARP My Viewlet web interface. At the top, the SHARP logo is on the left, and links for "Operation Manual Download" and "Sitemap" are on the right. Below these is a language dropdown set to "American English" and a search bar. A navigation bar contains tabs for "Status", "Address Book", "Document Operations", "User Control", and "System Settings". The "Machine Identification" section is active, showing a list of options on the left: "Machine Identification", "Total Count", "Device Status", "Network Status", "Firmware Version", "Power Reset", "Data List", "List for User", and "List for Administrator". The main content area displays the "Machine Identification" page with an "Update(R)" button and a printer icon. Below the icon, the following information is shown:

Unit Serial Number:	7F00053700
Name:	MySharp_1
Model Name:	
Machine Location:	1st floor west by PK
Current Status:	Online
Memo:	Not Set

At the bottom, there is a "Supply Status" tab and a large "Select Login" button. A red arrow points to a "Login" button in the top right corner of the interface.

Slide 4

SHARPAmerican English ▾

Login

Login(P)Cancel(C)

Authority:admin
Login Name:Administrator ▾
Password:.....(5-255digit)


Please enter the User Authentication information. This message can be edited from System Settings.

Login(P)Cancel(C)

Enter the **Password**. Select **Login**.

^ Top of Page

Slide 5



SHARP

Operation Manual Download Sitemap

American English

Login

Status Address Book Document Operations User Control **System Settings**

Machine Identification

Update(R)

Unit Serial Number: 7F00053700
Name: MySharp 1
Model Name:
Machine Location: 1st floor west by PK
Current Status: Online
Memo: Not Set

supply s **Select System Settings.** ^ Top of Page

Slide 6

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Home Screen Settings Copy Settings Printer Settings

Image Send Settings Document Filing Settings Sharp OSA Settings

Common Settings Network Settings Security Settings

Energy Save

System Init. Install. Settings

Select Energy Save.

Top of Page

Slide 7

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Energy Save

Eco Setting

Eco Scan Setting

Energy Saving Pattern List

Specific Date Operation Settings

Power ON/OFF Schedule Setting

Toner Save Mode

Eco Setting

Submit(U) Update(R) Back to Menu List

☐ Eco Recommendation Function Display

☐ Display Message When Extending Transition Time to Preheat/Auto Power Shut-Off Mode

Mode Setting:

☒ Custom

☐ Eco

Check Setting

Select Eco Setting.

Preheat Mode Setting: 1 min.(1-120)

Top of Page

Slide 8

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Energy Save

Eco Setting

Eco Scan Setting

Energy Saving Pattern List

Specific Date Operation Settings

Power ON/OFF Schedule Setting

Toner Save Mode

Eco

Check Setting Value of Each Mode(C)

Preheat Mode Setting: 1 min.(1-120)

☒ Turn off Panel Display during pre-heat mode

☐ Auto Power Shut-Off

☒ As soon as the remote job is finished, enter Auto power shut off mode.

Earliest

1 min (1-120)

Top of Page

Select **Auto Power Shut-Off.**

Slide 9

SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Energy Save

Eco Setting

Eco Scan Setting

Energy Saving Pattern List

Specific Date Operation Settings

Power ON/CFF Schedule Setting

Toner Save Mode

☒ Turn off Panel Display during pre-heat mode

☒ Auto Power Shut-Off

☒ As soon as the remote job is finished, enter Auto power shut off mode.

☒ Fix transition time. Auto Power Shut-Off Timer: ☐ Earliest

☐ Change transition time by time of day. ☒ Auto

☐ Manual


1 min.(1-120)

Original Eco Pattern1

Set the Auto Power Shut-Off Timer.

Top of Page

Slide 10



SHARP

Operator Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Energy Save

Eco Setting

Eco Scan Setting

Energy Saving Pattern List

Specific Date Operation Settings

Power ON/OFF Schedule Setting

Toner Save Mode

Check Setting Value of Each Mode(C)

Preheat Mode Setting: 1 min.(1-120)

☒ Turn off Panel Display during pre-heat mode

☒ Auto Power Shut-Off

☒ As soon as the remote job is finished, enter Auto power shut off mode.


☐ Fix transition time. Auto Power Shut-Off Timer: ☐ Earliest

1 min.(1-120)

Select the Preheat Mode Setting.

Top of Page

Slide 11



SHARP

Operation Manual Download Sitemap

American English

User Name: Administrator Logout

Status Address Book Document Operations User Control **System Settings**

Energy Save

➤ Eco Setting

Eco Scan Setting

Energy Saving Pattern List

Specific Date Operation Settings

Power ON/OFF Schedule Setting

Toner Save Mode

☒ Auto Power Shut-Off

☒ As soon as the remote job is finished, enter Auto power shut off mode.

☒ Fix transition time. Auto Power Shut-Off Timer: ☐ Earliest

☐ Change transition time by time of day. ☒ Auto ☐ Manual

1 min.(1-120)

Original Eco Pattern1

Sleep Mode Power Level:

Select Submit.

Submit(U) Update(R)

Top of Page

Slide 12

Congratulations, you have completed Setting the Power On and Power Off Schedule.



The image shows two Sharp MX-B376W and MX-B476W multifunction copiers in a modern office environment. The copiers are white with grey accents and feature a control panel with a color touchscreen. The background shows a blurred office scene with people working at desks. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W