


Slide 1


Setting the Paper Type.




The image shows two Sharp MX-B376W and MX-B476W multifunction copiers in a dimly lit office environment. The copiers are white with multiple paper trays and a control panel. The background shows a blurred office scene with people working at a desk. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W


Slide 2




Slide 3




Slide 4




Slide 5




Slide 6




Slide 7




Slide 8



Slide 9




Slide 10



Slide 11

Congratulations, you
have set the Paper Type.

The image shows two Sharp MX-B376W and MX-B476W multifunction copiers in a modern office setting. The copiers are white with grey accents and feature a control panel with a color touchscreen. The background is a dark, stylized office scene with silhouettes of people working. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W