

Slide 1


Total Count.




The image shows two Sharp multifunction copiers, the MX-B376W and MX-B476W, in a modern office environment. The copiers are white with grey accents and feature large touchscreens. The background shows a blurred office scene with people working at desks. The Sharp logo and 'mv' trademark are visible in the top right corner.

MX-B376W
MX-B476W


Slide 2




Slide 3



Slide 4



Slide 5



Slide 6

The screenshot displays the 'Settings' application interface. At the top, there is a 'Settings' header with a wrench icon, a 'Cancel' button, and status indicators for 'LINE' (disabled) and 'PRINTER' (enabled). A 'Job Status' button is also present. Below the header, there are three main tabs: 'Status', 'User Control', and 'System Settings'. The 'Status' tab is active, showing a list of status-related items on the left: 'Machine Identification' (highlighted with a blue bar and a red arrow), 'Total Count', 'Device Status', 'Network Status', 'Firmware Version', 'Power Reset', 'Data List', 'List for User', and 'List for Administrator'. The main content area on the right is titled 'Machine Identification' and contains an 'Update' button. Below the button, there is a table of machine information:

Unit Serial Number:	7F00053700
Name:	MySharp_1
Model Name:	
Machine Location:	1st floor west by PK
Current Status:	Online
Memo:	Not Set

Below the table, there is a 'Supply Status' section. At the bottom of the interface, there is a 'Select Total Count.' button and a 'Top of Page' button.

Slide 7

Settings Cancel ☐ ITNF ☒ PRINTER Job Status

Status User Control System Settings Administrator Login

Machine Identification

➤ Total Count

Device Status

Network Status

Firmware Version

Power Reset

Data List

List for User

List for Administrator

Status > Total Count

Total Count ☆

Print Update

Updated Time: 2018/05/24 15:32:13

Total Count	Count Number
Black & White	5940
Full Color	0

The **Total Counts** are displayed.

Copy 3893 ^ Top of Page

Slide 8

The screenshot shows the 'Settings' interface with the 'Status' tab selected. The left sidebar lists various settings, with 'Total Count' highlighted. The main area displays the 'Status > Total Count' page, which includes a table of counts for different functions and a 'Print' button. A red arrow points to the 'Print' button, and a text box explains that to print the Total Counts, the Print button should be selected.

Settings Cancel ☐ LINE ☒ PRINTER Job Status

Administrator Login

Status User Control System Settings

Machine Identification

Total Count

Device Status

Network Status

Firmware Version

Power Reset

Data List

List for User

List for Administrator

Status > Total Count

Scan Send	Black & White	23
	Full Color	23
Fax Send		0
Scan to HDD	Black & White	0
	Full Color	0

Device Name	Count Number
Document Feeder	
Duplex	

Print Update

To print the **Total Counts**, select **Print**.

Slide 9

The screenshot shows the 'Settings' application interface. The top bar includes a 'Settings' icon, a 'Cancel' button, and a 'Job Status' dropdown set to 'Printing'. Below the top bar are tabs for 'Status', 'User Control', and 'System Settings'. The 'Status' tab is active, and the 'Total Count' option is selected in the left sidebar. The main content area displays the 'Total Count' page, which includes a 'Print' button, an 'Update' button, and a confirmation message: "Your request was successfully processed." The 'Updated Time' is 2018/05/24 15:35:50. Below this, a table shows the 'Total Count' for 'Black & White' (5940) and 'Full Color' (0). A text box at the bottom states "A confirmation message is displayed."

Total Count	Count Number
Black & White	5940
Full Color	0

Slide 10

Congratulations, you have accessed
the Total Counts.



MX-B376W
MX-B476W

